



Managing Ice Events

Top 10 Tips for Managing Ice Events with Liquids



- Salt brine = salt + water
- Quality additives and their benefits
- Pre-treatment, Direct liquid (post-treatment), inter-storm





1. Pretreatment Timing
2. Use a Quality Additive
3. Reapply at Transition
4. Increase Application Rate
5. Quality Mechanical Scrape





6. Direct Apply After Event

7. Remember Sidewalks and Curb Edges

8. Use Manual Mode

9. Monitor Ongoing Weather

10. Don't Get Discouraged If (When) the
Weatherman is Wrong!